





## Coupling Series KB6P



RoHS

### General Information

The installation and operation instructions are an essential fact of the KBK coupling. It indicates tips for proper assembly, operation and maintenance. Please read these instructions carefully, and follow the instructions.

### Safety Instructions

 <b>Attention!</b>	<ul style="list-style-type: none"><li>- Installation may be performed by trained and specialized staff only.</li><li>- Rotating couplings are hazard areas. The user/operator has to ensure appropriate protective measures. Do not reach into the operation area of the coupling if it is still in operation. Secure the machine against unintentional power-up during assembly work.</li></ul>
--	--

### Manufacturer's Declaration

In accordance with directive 2006/42/EG annex IIB, shaft couplings are no machines as per the machinery directive (MR), but components for installation in machines. Operation is not permitted, unless the requirements according to the machinery directives are complied with upon integration in the final product.





**Pluggable metal bellows coupling with outer cones: KB6P**



**Function**

KBK metal bellows couplings are flexible shaft couplings. The metal bellows compensates lateral, axial and angular shaft misalignment with low restoring forces.

 <p><b>ATTENTION!</b></p>	KBK metal bellows couplings may only be used in accordance with the technical data mentioned in the catalogue. Any subsequent processing is not permitted.
--	--

**Preparation for assembly**

During assembly and disassembly, the metal bellows must not be deformed more than three times higher than the permissible misalignment value stated in the catalogue. Avoid using any force. The shafts and bores of the hub must be free from dirt and burrs. Please check the connection dimensions of the shafts (as well as the dimensions regarding the key) and check the tolerances. KBK metal bellows couplings have an H7 fit. This fitting tolerance and oiling the stub shaft, facilitate both assembly and disassembly. The recommended fitting tolerance is 0,02mm-0,05mm.

 <p><b>Attention!</b></p>	Any oils and fats containing molybdenum disulfide or any other high-pressure additives as well as lubricating pastes must not be used.
--	--





## Assembly

Determine the installation dimension of the coupling prior to the assembly. This is the only way to assure that the pretension  $V$  (table 2) on the coupling is reached. For this purpose plug the coupling together, without backlash and without any axial pressure. The installation dimension is calculated from the length  $L$  minus the pretension  $V$  (installation dimension =  $L - V$ ). Slide both hubs onto the shafts. In the correct axial position, tighten the clamping screws (F/G) evenly in a crosswise pattern to the torque stated in the table, by using a torque wrench. When pushing the coupling together, the pretension  $V$  of the bellows must be clearly noticeable.




Table 1 - Torque

KB6P /	18	30	60	150	300	500
$T_A$ (Nm) (F/G)	4,3	6,5	8	12	30	32

Table 2 - Pretension V


KB6P /	18	30	60	150	300	500
V (mm)	0,5-1,0	0,5-1,0	0,5-1,5	0,5-1,5	0,5-1,5	0,5-2,0

## Disassembly

For disassembly of the KBK metal bellows coupling, loosen the clamping screws (F/G). The cone is self-disengaging.

## Maximum misalignment

KBK metal bellows couplings compensate lateral, axial and angular shaft misalignment.





$$\sum \left[ \frac{\Delta r}{\Delta r_n} * 100\% + \frac{\Delta a}{\Delta a_n} * 100\% + \frac{\Delta w}{\Delta w_n} * 100\% \right] < 100\%$$

Definition	
$\Delta r$	Radial misalignment ( installed condition )
$\Delta a$	Axial misalignment ( installed condition )
$\Delta w$	Angular misalignment (installed condition)
$\Delta r_n$	Maximum permissible radial misalignment ( according to catalogue )
$\Delta a_n$	Maximum permissible axial misalignment (according to catalogue)
$\Delta w_n$	Maximum permissible angular misalignment (according to catalogue)



**Information!**

The maximum guideline value for the different misalignments can be found in our catalogue under 'technical information'. They provide security to compensate operation-related external influences e.g. thermal expansions and / or sinking foundation.



**Attention!**

Lateral misalignment has a negative effect on the service life of the metal bellows. An exact alignment of the coupling increases the service life considerably. The load for neighboring bearings is reduced and this will have a positive effect on the running smoothness of the entire driveline.

### **Maintenance**

KBK metal bellows couplings are maintenance-free. Regular inspection intervals should include a visual check of the KBK metal bellows couplings. If KBK metal bellows couplings are used as intended, they will have a long-lasting durability.

### **Transportation**

KBK metal bellows couplings are delivered ready for installation. Upon incoming goods inspection the metal bellows couplings should be stored in their original packaging and in this way they should be made available for installation. Operating and installation instructions should be always accessible for everybody at the installation location upon installation.

